

Using port forwarding on a FortiGate unit

This example illustrates how to use virtual IPs to configure port forwarding on a FortiGate unit, which redirects traffic from one port to another. In this example, incoming connections from the Internet are allowed access to a server on the internal network by opening TCP ports in the range 7882 to 7999 and UDP ports 2119 and 2995.

1. Creating three virtual IPs
2. Adding the virtual IPs to a VIP group
3. Creating a security policy
4. Results



